

AG05

**RSLogix™ 5000 EtherNet/IP™
Add-On Instruction via
Anybus® Communicator™**

Software Description



Table of contents

1	General Notes.....	3
1.1	Trademarks	3
1.2	Liability	3
1.3	Limitations.....	3
1.4	Requirements.....	3
1.5	Versions Overview.....	4
1.6	List of Abbreviations.....	4
2	Setup of Anybus® Communicator™	5
2.1	ABC Configuration File	5
2.2	TCP/IP Configuration	5
2.3	ABC Cycle Time.....	6
3	I/O Configuration in the Scanner	7
3.1	I/O Configuration with RSLogix™ 5000 Version 19 or Lower.....	7
3.1.1	Add New Module to the Hardware Configuration	7
3.2	I/O Configuration with RSLogix™ 5000 Version 20 or Higher.....	10
3.2.1	Register the EDS File for ABC	10
3.2.2	Add New Module to the Hardware Configuration	10
4	Software Configuration	12
4.1	Import the SIKO AG05 Add-On Instruction	12
4.2	Call the AOI SIKO_AG05 Cyclically in the User Program.	13
4.3	Setup Add-On Instruction Parameters	14
4.3.1	SIKO_AG05.....	14
4.3.2	DC_OutputBuffer.....	14
4.3.3	DC_AbcOutputRegister	15
4.3.4	DC_AbcStartByteOut	15
4.3.5	DC_InputBuffer.....	15
4.3.6	DC_AbcInputRegister	15
4.3.7	DC_AbcStartByteIn	15
4.3.8	nNodeId	16
4.4	AOI Call After Configuration	16
4.5	Software Example	17
4.5.1	Data Exchange.....	17
4.5.2	Parameter Access	17
4.5.3	Read Parameters	17
4.5.4	Write Parameters.....	17
4.5.5	Copy Parameters from Read to Write	17
4.5.6	S-Commands.....	17
4.5.7	Counter Value	18
4.5.8	Error Codes.....	20

1 General Notes

1.1 Trademarks

All trademarks or brand names including those protected for third parties shall unconditionally be subject to the provisions of the applicable laws governing trademarks and the proprietary rights of the registered owners. All trademarks, brand names or firm names are or may be trademarks or registered trademarks of their respective proprietors and are used only for description and unique identification. All rights not explicitly granted here are reserved.

Failure to explicitly identify trademarks used in this manual does not indicate that a name is free from rights of third parties.

Windows®, Windows® XP are trademarks of Microsoft® Corporation in the USA and other countries.

Anybus® is a registered trademark of HMS Industrial Networks AB, Sweden, USA, Germany and other countries.

Allen-Bradley®, ControlLogix®, CompactLogix™, MicroLogix™ and RSLogix™ 500, RSLogix™ 5000 are trademarks of Rockwell Automation®, Inc.

EtherNet/IP™ is a trademark of ODVA, Inc.

1.2 Liability

SIKO GmbH assumes no warranty whatsoever regarding topicality, correctness, completeness or quality of the information or software products provided. All liability claims against SIKO GmbH referring to material or immaterial damages caused by using or not using the information or software provided or by using erroneous or incomplete information or software are always excluded.

1.3 Limitations

The Add-On Instruction and its function were tested on a CompactLogix® 1769-L16ER. The module was programmed using RSLogix™ 5000 version V20.01.00 (CPR 9 SR 5).

The configuration file and its function were tested on an Anybus® Communicator™ AB7007. The file was setup using Anybus® Configuration Manager - Communicator RS232/422/485 version v.4.4.1.3 (Win 2000/XP/Vista/7).

1.4 Requirements

- Basic knowledge of handling and programming Allen-Bradley® systems.
- Familiarity with EtherNet/IP™.
- Basic knowledge of setup and handling Anybus® Communicator™
- Familiarity with Anybus® Configuration Manager

1.5 Versions Overview

This manual is related to

- AG05 firmware version >= 2.03
- Add-On Instructions "SIKO_AG05_RSLV19-01-00_V5-0-1.L5X"
- Add-On Instructions "SIKO_AG05_RSLV20-01-00_V5-0-1.L5X"
- Anybus® configuration file "SIKO_EIP_31-SN5_pattern.cfg"
- Anybus® Communicator™ file "005A000C004D0300.EDS"

1.6 List of Abbreviations


EIP	EtherNet/IP™	ABC	Anybus® Communicator™
SW	Status Word	ACM	Anybus® Configuration Manager
CW	Control Word	AOI	Add-On Instruction

2 Setup of Anybus® Communicator™

Please note, that the Anybus® configuration file is designed for a flexible SIKONETZ-5 participant numbers of minimum 1 to maximum 31. Only the TCP/IP configuration has to be modified according to your network requirements. Please consider an IP Address modification when reading further on.

2.1 ABC Configuration File

Start ACM and select configuration file "SIKO_EIP_31-SN5_pattern.cfg" from the folder "Anybus Config".




2.2 TCP/IP Configuration

NOTICE

The IP settings in this example can cause serious network problems under certain circumstances. If you are in doubt about the correct IP settings for your network, ask your system administrator for assistance.


Modify TCP/IP configuration if necessary.



1. Press "Connect" to go online with the ABC.

2. Press “download to the ABC”.

You should have the following view:



2.3 ABC Cycle Time

Each transaction consists of “Query” and “Response”. The minimum time for a used transaction is about ≥ 10 ms. Each Subnetwork cycle has an overhand of about ≥ 100 ms.

Since the plc cycle time is asynchronous with ABC cycle time the AOI integrates a trigger instead of checksum to the SIKONETZ-5 structure. When a master telegram is completed by the AOI the trigger will be incremented. The corresponding transaction will be updated by change of state on trigger and exchanges the trigger with checksum byte before the SIKONETZ-5 telegram is send into subnetwork.

The subnetwork reply is checked and checksum byte is exchanged with incrementaed trigger byte before the telegram is send to plc by ABC. The AOI will wait until a valid slave telegram is responded before sending a new telegram. Due to it the minimum time between update cycle amounts to ≥ 110 ms minimum. Please consider this for time critical applications!

3 I/O Configuration in the Scanner

From software version 20 onwards, EDS files are used for the I/O configuration.

Up to and including software version 19, the I/O configuration is carried out without EDS files.


3.1 I/O Configuration with RSLogix™ 5000 Version 19 or Lower

3.1.1 Add New Module to the Hardware Configuration


NOTICE

The IP settings in this example can cause serious network problems under certain circumstances. If you are in doubt about the correct IP settings for your network, ask your system administrator for assistance.

1. Right-click on "Ethernet" and execute "New Module..." command from the context menu.




2. Open "Communications" and select "ETHERNET-MODULE / Generic Ethernet Module".



3. Complete the selection with "OK".


4. Enter the module settings:



Settings	Description
1. Name	Name of device, in this example we use "Anybus"
2. Comm Format	Data format for the assembly object instances: "Data – SINT"
3. IP Address	IP address of the Ethernet-Module.
4. Input	Assembly object instance input: "100" with size "314"
5. Output	Assembly object instance output: "150" with size "314"
6. Configuration	Assembly object instance configuration: "1" with size "0"

5. Complete the settings with "OK". Now the module properties window appears.

6. Go to the tab “Connection” and set further properties.




Settings	Description	Value
1. Requested Packet Interval	The RPI time specifies the intervals for the I/O data exchange between adapter and scanner. Supported RPI: 1 ... 3200 ms	"10.0"
2. Inhibit Module	Check/clear this box to inhibit/uninhibit your connection to the module. Inhibiting the module causes the connection to the module to be broken.	"clear"
3. Major Fault On Controller If Connection Fails While in Run Mode	Check this box to configure the controller so that failure of the connection to this module causes a major fault on the controller.	"clear"
4. Use Unicast Connection over EtherNet/IP	Select between Unicast and Multicast for EtherNet/IP connections.	"check"

7. Complete the settings with “OK”.

The I/O configuration is now complete.

The corresponding tags will then be created in the controller tags of the project.




8. Save the I/O configuration.

3.2 I/O Configuration with RSLogix™ 5000 Version 20 or Higher

3.2.1 Register the EDS File for ABC

1. Start “EDS Hardware Installation Tool” and use the EDS wizard to register the EDS file “005A000C004D0300.EDS”.




3.2.2 Add New Module to the Hardware Configuration


NOTICE

The IP settings in this example can cause serious network problems under certain circumstances. If you are in doubt about the correct IP settings for your network, ask your system administrator for assistance.

1. Right-click on “Ethernet” and execute “New Module...” command from the context menu (The View could differ depending on used hardware).




2. Search for “HMS” in the catalog.




3. Choose catalog number “AB7007”.
4. Execute “Create” command.

5. Enter "Name" of device, for example "ABC".
6. Setup "Ethernet Address" of the ABC (assign IP address via ACM to setup address)



7. Open "Change ..."



8. Choose "Electronic Keying" "Disable Keying"
9. Change "Input" and "Output" size to "314" "SINT".
10. Confirm settings as well as warning with "OK".

The I/O configuration is now complete.

The corresponding tags will then be created in the controller tags of the project.


Name	Alias For	Base Tag	Data Type
ABC:I			_005A:AB7007_85E5B736:I:0
ABC:I.ConnectionFaulted			BOOL
ABC:I.Data			SINT[314]
ABC:D			_005A:AB7007_0C170748:D:0
ABC:D.Data			SINT[314]

11. Save the I/O configuration.


4 Software Configuration

4.1 Import the SIKO AG05 Add-On Instruction

1. Right-click on “Add-On Instructions” folder inside the controller organizer.
2. Execute command “Import Add-On Instruction...”.




3. For RSLogix™ 5000 V19 choose file “SIKO_AG05_RSLV19-01-00_V5-0-1.L5X” or for RSLogix™ 5000 V20 choose file “SIKO_AG05_RSLV20-01-00_V5-0-1.L5X” from the folder “AddOn Instruction”.



4. Execute “Import...” command.

4.2 Call the AOI SIKO_AG05 Cyclically in the User Program.

1. Double-click on “MainRoutine” folder.
2. Go to language element toolbar.
3. Choose tab “Add-On”.
4. Drag add-on “SIKO_AG05”.
5. Drop add-on at rung “0”.



4.3 Setup Add-On Instruction Parameters

After inserting the Add-On Instruction, you'll have to assign the various parameters of the module.


4.3.1 SIKO_AG05

Description: Module instance name

1. Create new tag by right-clicking on interrogation mark on the right side of "SIKO_AG05".
2. Execute "New Tag..." command.



3. Enter the name of the new tag, for example "Position1".



4. Confirm setting with "Create".

4.3.2 DC_OutputBuffer

Description: Buffer for protocol output transfer

1. Create new tag by pressing "Ctrl + W".
2. Enter the name of the new tag, for example "Position1_CW".
3. Confirm setting with "Create".

4.3.3 DC_AbcOutputRegister

Description: Data output register from ABC

1. Create new entering by double-click “?”.
2. Select drop-down menu.
3. Select “ABC:O” by double-click.
4. Confirm setting with “ENTER”.

4.3.4 DC_AbcStartByteOut

Description: Address of ABC memory field for outgoing data

1. Create new entering by double-click “?”.
2. Enter the number of the field in decimal format. First no. is “204”. A further AG05 will start 10 Byte higher, i. e. “214”, “224” and so on.
3. Confirm setting with “ENTER”.

4.3.5 DC_InputBuffer

Description: Buffer for protocol input transfer

1. Create new tag by “Ctrl + W”.
2. Enter the name of the new tag, for example “Position1_SW”.
3. Confirm setting with “Create”.

4.3.6 DC_AbcInputRegister

Description: Data input register from ABC

1. Create new entering by double-click “?”.
2. Select drop-down menu.
3. Select “ABC:I” by double-clicking.
4. Confirm setting with “ENTER”.

4.3.7 DC_AbcStartByteIn

Description: Address of ABC memory field for incoming data

1. Create new entering by double-click “?”.
2. Enter the number of the field in decimal format. First no. is “4”. A further AG05 will start 10 Byte higher, i. e. “14”, “24” and so on.
3. Confirm setting with “ENTER”.


4.3.8 nNodeId

Description: nNodeId is the temporary node address of each SIKONETZ-5 participant.

1. Create new entering by double-click “?”.
2. Enter the node address, for example “25”.
3. Confirm setting with “ENTER”.

NOTE: Before writing the parameters adjust parameter p00_NodeAddress_w accordingly!

4.4 AOI Call After Configuration



4.5 Software Example

4.5.1 Data Exchange

The AOI is designed to send or receive in alternation the “nSetValue” (Write, Parameter: 0xFF “Set Point 2”) or the “nActualValue” (Read, Parameter: 0xFE “Actual Position”) respectively, while no specific parameter access is active.

With the “nParameterAdrRead1”, “nParameterAdrRead2” and “nParameterAdrRead3” further parameter can be included in the data read cycle. With default value 0xFE the inclusion is disabled.

NOTE: If “bsFaultDataReceive” is indicated the complete data exchange is stopped, while Control and Status Word are still updated! A missing or not responding subnetwork participant is indicated by “bsComTimeout” (0,5sec. + time set in parameter 0x02 Bus Timeout).

4.5.2 Parameter Access

The present module contains the parameter data in addition to the process data (CW/SW). Parameters that can be changed (read/write) exist in programming as actual value (_r) and as target value (_w) as well. Furthermore, it is differentiated between pure read parameters (only indicated as actual value) and pure write parameters (only indicated as target value).

A rising edge must be applied either to the “bcStartRead” or to the “bcStartWrite” input on the module described here in order to enable a read or write process of one of the variables.

4.5.3 Read Parameters

If a rising edge is applied to the “bcStartRead” input, then all parameters will be read and can be used for further programming. If counter read value is not reset to “0” the read cycle was interrupted by read failure. This indicates to a communication failure.

4.5.4 Write Parameters

If a rising edge is applied to the “bcStartWrite” input of the module, then all parameters will be transferred to the module. If counter write value is not reset to “0” the write cycle was interrupted by a write failure. This indicates to a communication failure or parameter value is beyond range of value accepted by AG05.

4.5.5 Copy Parameters from Read to Write

If a rising edge is applied to the “bcStartCopy” input of the module, then all actual values (_r) are copied to their corresponding target values (_w).

4.5.6 S-Commands

After executing a S-Command a read cycle is been triggered to refresh all actual values (_r).

4.5.7 Counter Value

Count read value	Count write value	Name	Value range (dec)	Default
	1	0xA8 Programming Mode On/Off	0 ... 1	0
1	2	0x00 Note address	0 ... 31	1
2	3	0x01 Baud rate	0 ... 2	1
3	4	0x02 Bus Timeout	0 ... 20	20
4	5	0x03 Response parameter to a setpoint write access	0 ... 8	1
5	6	0x04 Keys enable time	1 ... 60	3
6	7	0x05 Key function enable	0 ... 1	0
7	8	0x07 LED 2 orange	0 ... 1	1
8	9	0x08 LED 1 red	0 ... 1	1
9	10	0x09 LED 1 green	0 ... 1	1
10	11	0x0A Decimal places	0 ... 4	0
11	12	0x0B Display divisor	0 ... 3	0
12	13	0x0C Direction indication function	0 ... 2	0
13	14	0x0D Display orientation	0 ... 1	0
14	15	0x0E Programming mode Configuration	0 ... 1	0
15	16	0xF PIN change	0 ... 99999	0
16	17	0x10 Controller parameter P	1 ... 500	300
17	18	0x11 Controller parameter I	0 ... 500	2
18	19	0x12 Controller parameter D	0 ... 500	0
19	20	0x13 a - Pos	1 ... 100	50
20	21		Gear 66:1 => 1 ... 75 98:1 => 1 ... 50	10
		0x14 v - Pos		
21	22	0x15 a - rot	1 ... 100	50
22	23	0x16 a - inch	1 ... 100	50
23	24		Gear 66:1 => 1 ... 75 98:1 => 1 ... 50	10
		0x17 v - inch		
24	25	0x18 ü - Numerator	1 ... 10000	1
25	26	0x19 ü - Denominator	1 ... 10000	1
26		0x1A Encoder resolution		720
27	27	0x1B Sense of rotation	0 ... 1	0
28	28	0x1C Spindle pitch	0 ... 1000000	0
29	29	0x1E Offset	-999999 ... 999999	0
30	30	0x1F Calibration value	-999999 ... 999999	0
31	31	0x20 Pos- window	0 ... 1000	10
32	32	0x21 Pos type	0 ... 2	0
33	33	0x22 Loop length	0 ... 30000	360

Count read value	Count write value	Name	Value range (dec)	Default
34	34	0x23 Inpos mode	0 ... 2	0
35	35	0x24 Delta Inch	-1000000 ... 1000000	720
36	36	0x25 Acceleration type with Inching mode 2	0 ... 1	0
37	37	0x26 Inchig 2 Offset	10 ... 100	100
38	38	0x27 Stop mode inching 2	0 ... 1	0
39	39	0x28 Operating mode	0 ... 1	0
40	40	0x29 Limit 1	-9999999 ... 9999999	99999
41	41	0x2A Limit 2	-9999999 ... 9999999	-19999
42	42	0x2C Current limiting	25 ... 110	110
43	43	0x2D Contouring error limit	1 ... 30000	400
44	44	0x30 Display value of 2nd line	0 ... 7	0
45	45	0x33 Display divisor application	0 ... 1	0
46		0x60 Output stage temperature		0
47		0x61 Voltage of control		0
48		0x62 Voltage of output stage		0
49		0x63 Voltage of battery		0
50		0x64 Motor current		0
51		0x65 Device code		0
52		0x66 Display controller software version		0
53		0x67 Motor controller software version		0
54		0x68 Serial number		0
55		0x69 Production date		0
56		0x6A Gear reduction		0
57		0x6B Actual position		0
58		0x6C Actual rotational speed		0
59		0x80 Number of errors		0
60		0x81 Error 1		0
61		0x82 Error 2		0
62		0x83 Error 3		0
63		0x84 Error 4		0
64		0x85 Error 5		0
65		0x86 Error 6		0
66		0x87 Error 7		0
67		0x88 Error 8		0
68		0x89 Error 9		0
69		0x8A Error 10		0
	46	0xAA FreezeAV	0 ... 1	0
70		0xFA System status word		0

Count read value	Count write value	Name	Value range (dec)	Default
71		0xFE Actual value		0
72		0xFF Set point		0
	47	0xA0 System Command	1 ... 9	0

4.5.8 Error Codes

If a communication error occurs, there is an error code present at the outputs "nErrorCode1" and "nErrorCode2". Please refer to the AG05 manual (keyword: error codes) for a complete description of these error codes.