
# **Diagnostic Tool DT20** for alignment of LSC20 to TS20

## **Profile**

- sensor alignment
- calibrating the sensor to the optical tape
- verifying sensor signals
- reading position values
- setting reference points
- setting limit switch positions





## Mechanical data

Feature	Technical data	Additional information
Housing	Metal	

## System data

Feature	Technical data	Additional information
Operating system	Windows 2000, Windows XP, Windows 7	

## **Ambient conditions**

Feature	Technical data	Additional information
Ambient temperature	0 40 °C	
Protection category	IP50	

**6 OptoLine** | 6.3 www.siko-global.com



## **Order**

ordering information

one or more system components are required: Optical Sensor LSC20

www.siko-global.com

Order key

**DT20** 

**Scope of delivery:** Software on CD, USB programming cable,
Connector power pack 110 ... 230 V AC, Mounting instructions on CD

